


TPL D/V.S C.C.T.V System

1080P Search Camera System

Quick Start Guide



Features and Specifications are subject to change without prior notice

8 Moshe Aviv St., Or Yehuda, 6037130 Israel
Tel: (972) 3 533 7019 Fax: (972) 3 533 7063

www.elpam.com
office@elpam.com



TPL D/V.S C.C.T.V System

Quick Start Guide

Version 1:

Version 2:

- > Waterproof IP68

> Audio Monitoring




Note:
It is sound default.Press to mute.
Press again, Speaker sounds.

0

Stretch and Retract Telescopic Pole


- > Stretch the cable, anti-clockwise loosen the loose collars one by one to stretch the pole. Then clockwise fasten the loose collars.Retract the pole:
- > Anti-clockwise loosen the loose collars one by one , then pull out the cable in end of the pole to retract the pole. Clockwise fasten the loose collars.



1

Install the 7" DVR


- > Aim the nut at the insert bolt on the pole,fasten Bolt with Chain. Fix the direction & angle by adjusting Bolt 2 & 3.
- > Catch the 5 pin connector to plug it into DVR female slot, then fasten the nut; When pull it out, just loosen it.



2

Power On/Off & Charge


- > Connect data cable first thenpress to turn on the DVR. press 3 seconds to power it off.
- > When low battery indicator appears, please use the DC12V AC adapter or USB 5V to charge it.
Note: (If system halted, please reset it)



3

Record & Photo


- > Under mode, press , DVR starts to record, and screen shows ,press again to end record.
- > Under mode,press once, screen flashes once, and get one picture.
ATTENTION: Do remember to insert the TF card.



4

Playback Video/Photo


- > Under mode, Press / to select the video files or photos, press to playback video or photos.
- > Press to exit.



5

Turn On/Off LED lights


- > Press to turn on LED lights, screen icon on.
- > Press again to turn off the LED lights, screen icon off.



6

Fuction Settings

- > Under mode,press ,to enter into function setting.Press / to select "function" press to confirm and exit.



7